

# REMOTE CONTROL VALVES

PanBlast remote control valves are for pressure vessel air inlet and/or air outlet control, and are available in both BSP and NPT thread configurations.



## Air Inlet valve variants include Sola, Tandem and Helix types.

- For small capacity blast pots



**Sola 5 Inlet Valve Assembly**  
CAT-0201-01-00  
Page 106 to 109



**Sola 5 NPT Inlet Valve Assembly**  
CAT-0201-02-00  
Page 110 to 113

- For small, large, pressure hold & bulk blast pots



**3/4" Tandem NPT Valve Assembly**  
CAT-0201-03-00  
Page 114 to 117



**1" Tandem NPT Valve Assembly**  
CAT-0201-04-00  
Page 118 to 121



**1-1/4" Tandem NPT Valve Assembly**  
CAT-0201-05-00  
Page 122 to 125



**1-1/2" Tandem NPT Valve Assembly**  
CAT-0201-06-00  
Page 126 to 129

- For medium capacity blast pots



**Sola 10 NPT Inlet Valve Assembly**  
CAT-0201-07-00  
Page 130 to 133

- For large capacity blast pots



**Sola 30 NPT Inlet Valve Assembly**  
CAT-0201-08-00  
Page 134 to 137

- For large capacity blast pots



**Helix100 Inlet Valve Assembly**  
CAT-0201-09-00  
Page 138 to 141



**Helix100 NPT Inlet Valve Assembly**  
CAT-0201-10-00  
Page 142 to 145

## AIR INLET



## Air exhaust valve variants include Sola, HiFlo, Diaphragm Dump and Helix types.

- Diaphragm activated



**Sola 5 NPT Exhaust Valve**  
CAT-0202-01-00  
Page 146 to 149

- Piston activated depressurization



**HiFlo NPT Exhaust Dump Valve Assembly**  
CAT-0202-05-00  
Page 162 to 165

- Fast diaphragm depressurization



**1" NPT Diaphragm Dump Valve**  
CAT-0202-04-00  
Page 158 to 161

- Piston activated depressurization



**Helix 50 Outlet Valve Assembly**  
CAT-0202-02-00  
Page 150 to 153



**Helix 50 NPT Outlet Valve Assembly**  
CAT-0202-03-00  
Page 154 to 157

- Cyclonic filtration of fines and dust from exhaust air



**AbraFlo NPT Abrasive Trap II Assembly**  
CAT-0202-06-01  
Page 166 to 169

## AIR EXHAUST



## Combination valve variants include UniFlo, Kombi and Helix 150.

- Durable duty
- Inlet/exhaust hose pinch combo



**Kombi NPT Remote Control Valve**  
CAT-0203-06-00  
Page 180 to 183

- Heavy duty
- Inlet/exhaust hose pinch combo



**Kombi II NPT Remote Control Valve**  
CAT-0203-07-00  
Page 184 to 187

- High flow
- Inlet/exhaust hose pinch combo



**Kombi III NPT Remote Control Valve**  
CAT-0203-10-00  
Page 188 to 191

- Lightweight
- Inlet/exhaust combo



**UniFlo Valve Assembly with Fittings**  
CAT-0203-02-00  
Page 172 to 175

- Modular
- Piston/diaphragm combination



**Helix 150 Valve Assembly**  
CAT-0203-08-00  
Page 192 to 195



**Helix 150 NPT Valve Assembly**  
CAT-0203-09-00  
Page 196 to 199

## COMBINATION



## Pinch valve variants include Pinch Valve and Safe-T-Pinch.

- Dual ram
- Safety spring closure
- Wide blast hose entry throat



**Safe-T-Pinch Valve Assembly**  
CAT-0204-02-00  
Page 204 to 207

- Single ram
- Rugged cast iron construction



**Pinch Valve NPT Assembly**  
CAT-0204-01-00  
Page 200 to 203

## PINCH

2